

2020 Truck Stop Shock Ranking & Applications

Ranking	Application (s)	Good	Better	Best
1	FL – 1995 to present - rear		89443	85724
2	FL – Columbia & Coranado Steer 2009-		85958	89449 (xf)
3	Low Susp. - Truck & Trl. Hendricson & SAF Holland	83128	85000	89436
4	INT 40k rear '06- ProStar , 9900 , Lonestar; '01- TranStar		85931	89458
5	PB - Set forward steer spring suspension 387, 389, 587 plus others		85062	89408
6	Vol. VN series, Rear : May 1999-2011		85066	89448
7	Volvo VNL 2012- rear			85088
8	FL - Century series, steer 1999 - 2009		85918	89449
9	Volvo Steer VNL, VNM, VNX 2011-			85098
10	FL FLD & Columbia Cab			83038
11	PB FlexAir & KW AirGlide 380		85067	89451
12	PB rear Low leaf air susp. 2004-		85069	89455
13	Int- ProStar Front Day Cabs, Sleepers -2014			85954
14	Vol. VN 2200 steer 1999-2010 / Mack Rear		85061	89450
15	KW Steer 2004-		85070	89459
16	KW, Mack, Nav. Steer -2013	83215	85001	89410
17	PB - steer spring suspension w/ set back axle	83219	85012	89413
18	KW & PB 384/579/589 Front air			85959
19	Nav IAS400 w/ 52" spacing		85923	89458 (xf)
20	Hendrickson/ Neway/Reyco Trailer Susp			85052
21	PB - Rear		85033	89427
22	KW rear 2006-		85936	89456
23	KW T680 & PB 579 Set Back Front			85989
24	KW T680 Front		85084	89440
25	Navistar Prostar Front on Sleeper 2013-			85995